

Two Piece Raceway

TPR-7560A	3/4" Two Piece Raceway Almond
TPR-7560W	3/4" Two Piece Raceway White
TPR-10060A	1" Two Piece Raceway Almond
TPR-10060W	1" Two Piece Raceway White
TPR-15060A	1 1/2" Two Piece Raceway Almond
TPR-15060W	1 1/2" Two Piece Raceway White



P/N: TPR-7560



P/N: TPR-10060



P/N: TPR-15060

Caution: Turn off power before you start. Trip the circuit breaker or remove the fuse controlling that circuit. Proper installation should comply with local codes. Use in indoor locations only.

Installation Instructions

1. Position the raceway next to the power feed source and cut the base to the desired length.
2. Peel off the adhesive-tape liner from the backside of the raceway base.
3. Press firmly into place in the desired layout.
4. Add outlet boxes, if required, and follow the installation instructions found on each box.
5. Secure the raceway to walls and ceilings with screws at 18" (.46m) spacing, and 1/2" (13mm) from each end. Place the wires into the base of the raceway.
6. After the wiring of the system is completed, cut the Raceway cover to the desired length, accommodating the necessary fittings.
7. Install the wiring devices and outlet box faceplate using the installation instructions found on each box.

