

# CableHider

FCL-7560A	3/4"	CableHider Cover Almond
FWH-7560A	3/4"	CableHider Base Almond
FCL-7560W	3/4"	CableHider Cover White
FWH-7560W	3/4"	CableHider Base White
FCL-15060A	1 1/2"	CableHider Cover Almond
FWH-15060A	1 1/2"	CableHider Base Almond
FCL-15060W	1 1/2"	CableHider Cover White
FWH-15060W	1 1/2"	CableHider Base White



**Caution: Turn off power before you start. Trip the circuit breaker or remove the fuse controlling that circuit. Proper installation should comply with local codes. Use in indoor locations only.**

## Installation Instructions

1. Position the raceway next to the power feed source and cut the base to the desired length.
2. Peel off the adhesive tape liner from the backside of the raceway base.
3. Press firmly into place in the desired layout.
4. Add outlet boxes, if required, and follow the installation instructions found on each box.
5. Secure the raceway to walls and ceilings with screws at 18" (.46m) spacing, and 1/2" (13mm) from each end. Push the wires into the CableHider base through its flexible lips.
6. After the wiring of the system is completed, cut the Raceway cover to the desired length, accommodating the necessary fittings.
7. Install the wiring devices and outlet box faceplate using the installation instructions found on each box.
8. Note: When running power cables, a CableHider base and cover must be used.